
CZS slit milling example

Tool	: CZS 4030-0800 (\$3 x 8)
Work materia	I : Copper C1100
Size	: Width 3 x Length 6 x Depth 1.5 mm
No. of slit	: 1,600 slit
Coolant	: Water soluble


Milling condition

Spindle Speed	Z-Feed Rate	XY-Feed Rate	a _p	Cycle Time
(min ⁻¹)	(mm/min)	(mm/min)	(mm)	
8,500	250	600	1.5	50 min



Workpiece after process

Tool after process



Although 1,600 slits were milled, the tool wear were small. Only the small chipping was in the center of bottom edge. There is no burr on the workpiece.

