


## 钛合金(Ti6Al4V)医疗部品 腿骨植入 加工案例







・工件尺寸 : \$\phi90 mm x 120 mm


・冷却方法 : 油性切削油・総加工時間 : 9時間30分

加工中心 : 三菱重工工作機械株式会社 μV1·CAD/CAM : 株式会社C&G系统 CAM-TOOL

・刀柄 : 株式会社MST Corporation









使用系列	工具形状	刀具尺寸	转 <b>速</b> (min <sup>-1</sup> )	进给 <b>速度</b> (mm/min)
CNRS	4刃 圆角刀	φ8 x CR1 x 16	2,800	700
CFB	3刃 球刀	R3 x 9	8,000	4,000
CFB	3刃 球刀	R2 x 6	12,000	4,000
CSELB	2刃 避空型球刀	R0.75 x L3	26,000	1,560
CFB	3刃 球刀	R2 x 6	12,000	4,000
CSELB	2刃 避空型球刀	R2 x L12	12,000	1,800
CFB	3刃 球刀	R1.5 x 4.5	16,000	4,000
CSELB	2刃 避空型球刀	R1.5 x L12	16,000	1,600

